

PRODUCT TIPS

1. For accurate hardware placement in vinyl or metal applications, pre-drilling of the window profile is recommended.
2. For vinyl window applications, mounting screws should pass through two PVC walls, or one PVC wall and one insert wall. For this reason, it may be necessary to use a longer screw than is recommended.
3. For metal window profiles, we recommend stainless-steel machine screws. However, in most applications, stainless-steel sheet metal screws will provide adequate holding power.

ARCHITECT SPECS

Window sash handles shall be included which will provide a positive grip on the sash for easy window operation. The sash handles shall be constructed of a high-pressure zinc alloy die casting. Sash lift will be 13314 series as manufactured by AmesburyTruth.