

## **PRODUCT TIPS**

1. When two locks are used on one window, the placement of each lock, with respect to its keeper becomes very critical to maintain a constant weather seal on all sides of the window and to ensure that each lock engages properly with its keeper.
2. For accurate hardware placement in vinyl or metal applications, pre-drilling of the window profile is recommended.
3. For vinyl window applications, mounting screws should pass through two PVC walls, or one PVC wall and one insert wall. For this reason, it may be necessary to use a longer screw than is recommended.

## **ARCHITECT SPECS**

Window check rail locks shall be included which increase both security and weather seal tightness. The lock must provide easy operation and positive locked feel (detent). Window check rail locks shall be of open cam design.