

PRODUCT TIPS

1. For accurate hardware placement in vinyl applications, pre-drilling of the window profile is strongly recommended.
2. For vinyl window applications, mounting screws should pass through two PVC walls, or one PVC wall and one insert wall. For this reason, it may be necessary to use a longer screw than is recommended.
3. For top mounted keeper configurations, a 0.3" minimum deep surface is needed on the fixed rail with both surfaces flush when closed.

ARCHITECT SPECS

Window lock will be of quick snap action bolt design. The product will be constructed of high-pressure zinc alloy die cast with high strength acetal bolt. Window lock shall have automatic latching to allow user to use both hands to move the sash. Window will be unlocked with a slide tab on the top cover. Window locks will be 19.63 series Positive Action Locks as manufactured by AmesburyTruth.